



REDUCER SERVICE MANUAL
&
ANTI BUZZING INSTRUCTION




REDUCER SERVICE

Tools and products:

- Reducer replacement kit 180/10025/C
- Torx T25 key
- Thread cutting device M10x1
- Thread cutting device M15x1
- Ring spanner size 8 and 17 mm
- Spanner socket 19 for nozzle assembly
- Torque spanner (0 -10 Nm) with socket 14 mm / 8 mm
- 14 mm socket with ratchet
- Screwdriver (flat head)
- Hammer
- Compressed air
- Brake cleaner / carburettor cleaner

Overview





Reducer replacement kit 180/10020

- Gas-side diaphragm
- Water-side O-ring
- Pressure relief valve O-ring
- Locking nut M5
- Jet
- Locating pin
- Valve seat
- Water-Gas 16mm elbow 3x
- O-ring ECT sensor



Loosen and remove the six Torx T25 screws (nr 32).

Do NOT loosen the "Tensilock-nuts" (nr25) itself -> this will harm the locking function.



Remove the front cover (nr 3).

The adjustable disc/screw (nr 2+4+21+15) in de front cover will be used again. Only the O-ring should be renewed.







Remove the back cover (nr 5).

Renew the O-ring (nr 17) of the back cover.

Be careful -> do not damage the O-ring groove!




	<p>Remove the diaphragm (nr 23).</p> <p><i>Remove (and renew) the diaphragm complete with locating pin, mounting plate, washer and locking nut (nr 20+19+28+24)</i></p>
	<p>Remove the jet (nr 18) and valve + spring (nr 31+13) from the main body.</p> <p><i>Use a special spanner socket 19 (099/9980) to disassemble the jet.</i></p> <p><i>Clean the threaded hole with a thread cutting device M15x1mm, break cleaner and compressed air.</i></p> 
	<p>Remove 16mm GAS and water elbows (nr 6).</p> <p>Remove the pressure relieve pillar and valve (nr 10, 11, 16)</p> <p>Remove the ECT sensor (nr30)</p> <p><i>Clean the main body thoroughly with break cleaner, cloth and compressed air.</i></p> <p><i>Renew the O-rings from the over pressure valve and ECT sensor.</i></p> <p><i>Renew the 3 elbows including the O-rings.</i></p> <p><i>Do not damage the O-ring groove!</i></p>

 	<p>IMPORTANT:</p> <p>In case the ECT sensor (nr 30) has to be renewed, please pay attention to the following:</p> <ul style="list-style-type: none"> - Older sensors are fitted with a brass/ALU ring. - New replacement ECT sensors have an O-ring. <p>Only use the O-ring in case the main body has special O-ring groove (see picture). In all other cases, we suggest to fit the sensor with Loctite and an ALU/brass ring.</p>
	<p>Fit the new valve (nr31) including the spring (nr 13).</p> <p>Fit on top of the valve, the jet (nr 18).</p> <p>Use a very small amount of locking compound threebond 1305 or equal</p> <p><i>Torque setting : 4 Nm</i></p>
	<p>Assemble the new diaphragm:</p> <p>Location pin (nr 19) -> mounting disc (nr 20) -> diaphragm (nr 23) -> washer (nr 28) -> tensi-lock nut (nr 24).</p> <p><i>Torque setting (nut): 2.5Nm</i></p>

Anti-Buzzing ring:

In case of noise issues (buzzing noise), it is possible to fit an anti-buzzing ring according the following steps

	<p>Be sure the adjustment mechanism is fitted in de front cover.</p>
 	<p>Position the anti-buzzing ring in the centre of the front cover as shown in the picture.</p> <p>Remark -> <i>the ring is conical. Be sure it is positioned with the right side up.</i></p> <p>Find yourself a round piece (like a spanner socket) with the right dimension to press the ring inside the front cover.</p> <p>Remark: <i>be sure there are no sharp edges or damages on the press tool-> the anti-buzzing ring may not be damaged -> damages will harm the diaphragm afterwards.</i></p>
	<p>Use a hydraulic press or workbench to press the ring into the front cover.</p> <p>Remark: <i>be sure the ring is 100% even with the inside of the front cover.</i></p> 
<p>Remark: in case of an old machined MAP front cover, the anti-buzzing ring will block the MAP pillar (connection). Please drill a 3mm hole through the MAP pillar and the anti-buzzing ring. Drill this hole <u>before</u> assembling the complete reducer.</p>	

	<p>Position the back cover and diaphragm and fit all bolts in place.</p> <p>Put the spring on top of the diaphragm and be sure everything is positioned correctly.</p>
	<p>Place the front cover and the tensi-lock nuts on top of the bolts.</p> <p>Tighten the M5 bolts with a torque of 8Nm</p> <p><i>Remark: Do not tighten the tensilock nut side, but the Torx bolt side</i></p>
	<p>Check:</p> <ul style="list-style-type: none"> - Check after installation if the reducer is not leaking (water/gas) - Check the car's coolant level after the engine has ran for about 10 minutes. - Adjust the reducer pressure according the desired/prescribed pressure.